CONTENTS

CHAPTER 1: SPECIFICATION

1. Specifications
SC3500 Hardware Specification 1-1
SC3500 Interface Specification 1-1
2. Comparison Chart 1-4
3. Applicable Risograph model 1-5

CHAPTER 2: HARDWARE INSTALLATION

1. Hardware Installation
1-1. Checking Your SC3500 Package 2-1
1-2. Computer System Requirements 2-1
1-3. Risograph System Requirements 2-2
1-4. Preparing the Risograph 2-2
1-5. Preparing the SC3500 (Including Expanding RAM module) 2-2
1-6. Connecting the Cables 2-4

CHAPTER 3: FIRMWARE PROGRAM

1. Firmware Program Version Check 3-1
2. Firmware Program Upgrading
1. Upgrading on Windows 3.1 3-2
2. Upgrading on Windows 95 3-4
3. Upgrading on MS-DOS 3-6

CHAPTER 4: TROUBLESHOOTING TIPS

1. Error Indicator on Front Panel 4-1
2. Operation Troubles 4-2
3. Hardware Troubleshooting Flowchart 4-5

CHAPTER 5: APPENDIX

1. Description of LED Display 5-1
2. Description of Panel Button 5-2
3. Inside Constraction 5-3
4. Theory of Data Processing 5-4
5. SC3500 Main PCB 5-5
6. How to Remove the Main PCB 5-6
7. Parts List 5-7
8. Test Print 5-8
9. Technical Support 5-9